


Going to the folder and unzip the file.

```
tar -zxvf safemate-amd64-2.0v.linux.tar.gz -C /tmp/
```

A terminal window titled 'root@ubuntu: /home/aa1/Desktop/miss' with a menu bar (File, Edit, View, Search, Terminal, Help). The terminal shows the following commands and output:

```
aa1@ubuntu:~$ su root
Password:
root@ubuntu:/home/aa1# cd Desktop/
root@ubuntu:/home/aa1/Desktop# cd miss/
root@ubuntu:/home/aa1/Desktop/miss# tar -zxvf safemate-amd64-2.0v.linux.tar.gz
-C /tmp/
safemate2.0v/
safemate2.0v/install.linux.sh
safemate2.0v/startup.add
safemate2.0v/shutdown.sh
safemate2.0v/SendMSG.sh
safemate2.0v/Readme
safemate2.0v/ups_netcomm
safemate2.0v/ups_status
safemate2.0v/ups_config
root@ubuntu:/home/aa1/Desktop/miss#
```

Enter the file

```
cd /tmp/safemate2.0v
```

To install

```
./install.linux.sh
```

Verify that the installation is successful .local file has the following three lines

```
cat /etc/rc.local
```

```
# BEGIN: Startup for UPS SafeMate
```

```
cd /etc/ups_safemate && ./ups_netcomm &
```

```
# END: Startup for UPS SafeMate
```

If not running, run the following command

```
cd /etc/ups_safemate && ./ups_netcomm &
```

Installation path : `/etc/ups_safemate/`

Adjust configuration parameters:

```
cd /etc/ups_safemate/
```

```
./ups_config
```

```
root@centos7 ~# ./ups_config
-----Welcome to SafeMate Config System-----
                                   Dec 18 2020 ver 2.0
++=====+The Current Time Settings +=====++
[F] System Shutdown Delay Time When AC Power Failed:  [300] Sec.
[L] System Shutdown Delay Time When Battery Low:      [60] Sec.
[U] System Shutdown Delay Time When UPS Bad:  [180] Sec.
-----++
[A]The Remote UPS IP address : [172.16.88.252]
[I]The Interval of warning : [10] Sec
[S] Save Configuration now!
[Q] Quit.
[T] Turn off UPS after System Shutdown: NO
[D] Turn off UPS Delay Time when system shutdown: 2 Min
++=====+comment+ =====++
| Please input the 'F' to set the delay time when AC Power Failed.
| Please input the 'L' to set the delay time when Battery Low.
| Please input the 'U' to set the delay time When UPS Bad.
| Please input the 'I' to set the Interval of warning.
| The system shutdown canceled if the delay time value is '-1'.
++=====Please input your command =====++
```

Unable to restart automatically after shutdown, please output instruction to start.