

SPIS TREŚCI	STRONA
1. WSKAZÓWKI DOTYCZĄCE BEZPIECZEŃSTWA	1
2. ZAWARTOŚĆ ZESTAWU	1
3. BUDOWA	2
4. UŻYTKOWANIE	2
5. ŁADOWANIE	2
6. INSTALACJA	3
7. SPECYFIKACJA	4
8. UTYLIZACJA	4
9. GWARANCJA	4

1. WSKAZÓWKI DOTYCZĄCE BEZPIECZEŃSTWA

Przed użyciem produktu prosimy o uważne zapoznanie się z treścią poniższej instrukcji oraz jej przechowanie w celu wykorzystania jej w przyszłości. W przypadku przekazywania produktu osobom trzecim, wskazane jest dołączanie do niego instrukcji.

Lampa jest urządzeniem precyzyjnym. Nie upuszczaj urządzenia, nie uderzaj, nie narażaj na wstrząsy.

Nie używaj urządzenia w pobliżu ognia, łatwopalnych środków i rozpuszczalników.

Nie wyciąkaj metalowych elementów w urządzenie.

Nie dotykaj części elektrycznych materiałami przewodzącymi.

Temperatura robocza w zakresie 0 - 40°C

Produkt będzie generować ciepło podczas pracy, proszę być ostrożnym z tym, aby uniknąć jakichkolwiek możliwych szkód.

Nie należy wpatrywać się bezpośrednio w włączony panel LED.

Do użytku przez osoby dorosłe.

Nie należy samodzielnie rozmontowywać urządzenia.

Rozkręcenie urządzenia spowoduje utratę gwarancji.

W przypadku gdy występują problemy z urządzeniem, należy dostarczyć je do autoryzowanego serwisu.

Ważne!

Kiedy urządzenie pokazuje niską moc, proszę doładować lampkę.

Gdy lampka nie jest używana przez długi czas, proszę ładować ją co 3 miesiące, aby zapewnić trwałość baterii.

Należy dokładnie zakrywać porty USB gumową zatyczką po ładowaniu, aby uniknąć obcych substancji.

Konserwacja

Do czyszczenia urządzenia używaj suchej i miękkiej szmatki. Odrobina neutralnego środka czyszczącego na szmatkę, aby usunąć uporczywe zabrudzenia. Nie należy używać silnych detergentów, jak rozcieńczalnik, benzyna czy alkohol, gdyż mogą doprowadzić do uszkodzenia powłok ochronnych.

2. ZAWARTOŚĆ ZESTAWU

Lampka Led LUNAR – 1 szt.

Statyw – 1 szt.

Kabeł USB-C – 1 szt.

3. BUDOWA

Wskaźnik naładowania akumulatora
Port ładowania USB-C
Włącznik / Wyłącznik / Przełączenie trybów
Karabińczyk
Gniazdo do bitów
Multifunkcyjny klucz
Zbijak do szyby
Otwieracz do butelek
Gwint 1/4 cala



4. UŻYTKOWANIE

Tryby świecenia:

Pojedyncze kliknięcia: zimne mocne światło / zimne słabe światło / ciepłe mocne światło / ciepłe słabe światło / czerwone światło ciągłe / czerwone światło migające
Przytrzymaj ON/OFF przez trzy sekundy: największa moc światła.

Aby wyłączyć: pojedyncze kliknięcie.

Funkcje produktu:

Karabińczyk – produkt wyposażony jest w karabińczyk, dzięki któremu przymocujesz go do wielu elementów.

Zbijak do szyby – jeśli będziesz musiał zbić szybę – dzięki odpowiedniemu elementowi w górnej części produktu zrobisz to w prosty sposób.

Otwieracz do butelek – dzięki któremu otworzenie butelki z kapsłem będzie sprawne.

Multifunkcyjny klucz – jeśli musisz przykręcić lub odkręcić śrubę nasadkową.

Mini wkrętak – z tyłu produktu znajdziesz cztery bity (dwa płaskie, dwa krzyżakowe), a pod włącznikiem/wyłącznikiem gniazdo na bity. Wyciągnij bit z uchwytu, a następnie włóż do gniazda bitów.


Gniazdo statywowe – w dolnej części produktu znajdziesz gniazdo, dzięki któremu w prosty sposób umieszysz statyw.

Proste ładowanie – z boku produktu znajduje się port USB Typ-C do ładowania.

5. ŁADOWANIE / ROZŁADOWYWANIE

Umieść kabeł USB Typ-C w gnieździe z boku produktu, a następnie podłącz do ładowarki. Lampka dostosuje prąd ładowania. Pełne naładowanie produktu zajmie około 1h.

Z tyłu produktu znajdują się cztery diody, które wskazują poziom naładowania



6. INSTALACJA

Karabińczyk



Statyw

W dolnej części lampki znajduje się gwint 1/4 cala. Umieść gwint w gnieździe lampki, a następnie wkręć statyw. Rozłóż nogi statywu i postaw na płaskiej nawierzchni.

Statyw możesz użyć również jako uchwytu do trzymania lampki. Wystarczy, że złapiesz złożone nogi statywu w swojej dłoni.



7. SPECYFIKACJA

Moc:	10W
Jasność:	Światło białe 460lm, światło żółte 420lm, światło białe + żółte 600lm
Pojemność akumulatora:	500mAh
Materiał:	stop aluminium, tworzywo sztuczne
Port ładowania:	Typ-C
Czas ładowania:	około 1h
Czas świecenia:	2-3h
Waga:	45g
Wymiary:	około 8 x 4,5 x 2,3cm
Tryb świecenia:	białe mocne światło, białe słabe światło, żółte mocne światło, żółte słabe światło, czerwone światło, czerwone światło migające, długie naciśnięcie: mocne światło

8. UTYLIZACJA



Symbol przekreślonego kosza oznacza, że zużytego sprzętu elektrycznego i elektronicznego, baterii i akumulatorów oraz opakowań nie wolno umieszczać z innymi odpadami domowymi. Muszą one być przekazane do oddzielnego systemu zbiórki odpadów.

9. GWARANCJA



Produkty Newell objęte są 40-miesięczną gwarancją producenta.



Producent/Importer: Fdirect sp. z o.o., ul. Rąbierska 18, 95-227 Łódź, Polska

Made in China, In China hergestellt, Hecho en China, Fabbriato in Cina, Fabriqué en Chine, Vyrobeno v Číně, Wyprodukowano w Chinach, Сделано в Китае.

CONTENTS	PAGE
1. SAFETY INSTRUCTIONS	1
2. SET CONTENT	1
3. CONSTRUCTION	2
4. USAGE	2
5. CHARGING / DISCHARGING	2
6. INSTALLATION	3
7. SPECIFICATION	4
8. WASTE MANAGEMENT	4
9. WARRANTY	4

1. SAFETY INSTRUCTIONS

Before using the product, please read the following instruction manual carefully and keep it for future reference. When transferring the product to a third party, it is advisable to include the instructions.

The lamp is a precision device. Do not drop, hit, crush or expose to any shock. The unit is not dustproof or waterproof. Store in a dry, cool and ventilated place. Do not expose to water or other sources of moisture.

Do not use near flammable materials and solvents.

Do not use the lamp too close to objects. Do not cover the ventilation holes. Do not insert metal parts into the lamp. Do not touch the electrical parts with conductive materials.

The lamp can operate in a temperature range of 0°C - 40°C.

The lamp will heat up slightly, but it is normal.

Do not stare directly at the LED panel that is turned on, it may cause eye damage.

Do not use the LED outside in direct sunlight for a long time.

Disconnect the power supply for storage or transportation. Do not lift the camera while holding the lamp handle.

Allow the unit to cool down before placing it in the package.

For use by adults.

If you notice smoke or a strange smell coming from the device, immediately disconnect the power. Do not disassemble. Disassembling the unit will void the warranty. If there are problems with the lamp, bring it to an authorized service center.

Important!

When the device shows low power, please recharge the lamp.

When not in use for a long time, please recharge it every 3 months to ensure the durability of the battery.

Please cover the rubber piece of USB ports well after recharging or discharging to avoid foreign matter.

Maintenance

Use a dry and soft cloth to clean the unit. Do not clean with water. A little neutral detergent on the cloth to remove stubborn dirt.

Do not use strong detergents such as thinner, benzene or alcohol as they may damage the protective coatings.

2. SET CONTENT

Led LUNAR lamp - 1 pc.

Tripod - 1 pc.

USB-C cable - 1 pc.

3. CONSTRUCTION

Battery charge indicator
USB-C charging port
On / Off / Mode switch
Snap Hooh
Socket for bits
Multifunction spanner
Window breaker
Bottle opener
1/4 inch thread



4. USAGE

Light modes:

Single clicks: cold strong light - cold weak light - warm strong light - warm weak light - red continuous light - red flashing light.

Hold ON/OFF for three seconds - highest light output.

To switch off - single click

Product features:

Snap Hooh - the product comes with a carabiner so you can attach it to many items.

Glass breaker - if you need to break a pane of glass, the glass breaker is an easy way to do this, thanks to the glass breaker at the top of the product

Bottle opener - makes opening a bottle with a cap a breeze

Multifunction spanner - if you need to tighten or loosen a socket screw

Mini screwdriver - on the back of the product you will find four bits (two flat, two crosses), and under the on/off switch a bit slot. Pull the bit out of the holder and then insert it into the bit socket.

Tripod socket - at the bottom of the product you will find a socket that makes it easy to insert a tripod

Simple charging - on the side of the product you will find a USB Type-C port for charging

5. CHARGING / DISCHARGING

Insert the USB Type-C cable into the socket on the side of the product and then connect to the charger. The light will adjust the charging current. It will take approximately 1h to fully charge the product.

There are four LEDs on the back of the product to indicate the level of charge



6. INSTALLATION

Snap Hooh



Tripod

There is a 1/4 inch thread on the bottom of the light. Place the tripod thread into the socket of the light and then screw in the tripod. Spread the tripod legs and place on a flat surface.

You can also use the tripod as a handle to hold the light. Simply grasp the folded tripod legs in your hand.



7. SPECIFICATION

Power:	10W
Brightness:	white light: 460lm , yellow light: 420lm , white + yellow light: 600lm
Battery capacity:	500mAh
Material:	Aluminium alloy, plastic
Charging port:	Typ-C
Charging time:	approximately 1h
Lighting time:	2-3h
Weight:	45g
Dimensions:	approx. 8 x 4.5 x 2.3cm
Light mode:	white strong light, white weak light, yellow strong light, yellow weak light, red light, red flashing light, long press: strong light

8. WASTE MANAGEMENT



The crossed-out trashcan symbol means that waste electrical and electronic equipment, batteries and packagings must not be placed with other household waste. They must be handed over to a separate waste collection system.

9. WARRANTY



Newell products are covered by a **40-month** manufacturer's warranty.

*The manufacturer reserves the right to change the information contained in this manual without prior notice.



Made in China, In China hergestellt, Hecho en China, Fabbriato in Cina, Fabriqué en Chine, Vyrobeno v Číně, Wyprodukowano w Chinach, Сделано в Китае.